WiFi Doctor User manual

Contents

Introduction	2
Requirements	2
Get Started	3
WiFi Doctor App	6
Site Survey Result	

Introduction

This guide shows you how to perform Wi-Fi site survey with WiFi Doctor App and get the survey result on the cloud platform.

Requirements

• Android Device with WiFi Doctor App installed

(Download link) https://play.google.com/store/apps/details?id=com.yfisoft.heatmap

• Internet access to Cloud Platform

https://cloud.yfisoft.com:60000

Get Started

- 1. Create Lavinet account
 - Go to https://cloud.yfisoft.com:60000



• Click "Don't have an LAviNet account? Create one now" to go to register page



• Complete the register form and click "Create Account"



2. Create Site and Map

- Login to cloud platform
- Go to menu > Site Settings > Create new site

AviNet		Ĺ
Create New Site		
SITE INFORMATION		
Name		
Туре 😡	Use External Gateway Use Lavinet Gateway	
Country code	US	•
Timezone	(GMT+08:00) Beijing, Chongqing, Hong Kong, Unumgi	•
SITE NETWORK		
Enable VLAN		
NTP server		
HEALTH CHECK		
Heartbeat Interval(s)	30	
Ping host address	127.0.0.1	
Ping Interval(s)	30	
Ping packet number 🛛 😡	4	
Submit		

- Complete the site form (use default value) and click 'Submit'
- Go to menu bar > Site Settings > Maps

	/AviNet
9	Manage Maps
۰	MAP INFO + Now X Distric
٠	9400
× 00	
	- NAME
	LATITUDE
	LONGITUDE
	200M
	Ubriti C 9460

- Click "New" to create a new map for site survey
- Change map name and upload an floorplan image (png/jpg/jpeg)
- Change the zoom level to adjust the map view which is comfortable to you

	(AviNet		۵ 😩
0	nage Maps	Home	
•	INFO INTERNATIONAL		
		. 1	
		_)¤ []	
	Anne E 10		
		0	
		0	
	атиас 90 30/517/10/4999	_	

• Click "Save"

- 3. Create WiFi Doctor Site survey Project
 - After creation of site and map, go to menu > WiFi Doctor

	_/Avinet		۵	
e.	WIFi Doctor	Home		•
۰	SITE SURVEY PANEL		+ New	
	+			
	Copyright © 2017 Yflant Limited Al rights reserved. Terms of use Princip Failog	Vec	ion 3.1	

• Click "New" and choose map for site survey

Name		
Map		
Please select a map		•
Preview		
Map Scale		
Map Scale Pixel(s) per meter		

(Please enter correct map scale as it will affect the accuracy of the result)

- Complete the form and click "Save"
- Now it is ready to perform site survey

WiFi Doctor App

- 1. Start survey
 - Login:



• After login, you will get your list of survey sites:



• Select the site that you want to do survey, then you will be redirected to a floor plan view:



• After pressing the play button on the bottom-left corner, the pause button appears, then WiFi scan starts, when a scan cycle is finished, a short toast will prompt:



• Tap on the user location of the floor plan, wait a few seconds, you will see a yellow point on the tapped location:



• After site survey is done, one can press the pause button, which will stop the WiFi scanning and all yellow points turn into red ones:



- User can modify/delete individual point(s) as needed:
 - First, select a point, a cyan circle will appear:

	🕅 🖀 🖹 76% 🗖 4:21
Edit Mode	:
* 0 0	
	ବି ଦି ବି ଦି ବି ଦି

- After selecting a point, if removal is required, press the rubbish bin button at the bottom, the selected point will be gone.
- After selecting a point, if one wants to shift the location, long press at the target location, then the point will be moved to the target.
- When everything looks fine, one can upload the survey points to cloud server by pressing the "upload data" button in the menu on the top:



• After successful upload, red points will turn green and user can no more edit green points from the phone:



- The "download data" button in the menu will reload the green points from remote and will not affect the red and yellow ones.
- User can enable active survey by using the "Iperf3 config" button in the menu, (note: a iperf3 server is needed, download iperf3 https://iperf.fr/iperf-download.php) :

🖂 🖞 N	🔊 🐔 📉 98% 🖪 6:33
Wifi Doctor	
IPERF3 PARAMS:	
-c 192.168.250.130 -p connect-timeout 1000	5201 -J -t 2 -O 5
Enable iperf3 active sca	n
SAVE	E
CANCE	EL

Site Survey Result

You can go to WiFi Doctor Admin page and check the result after the survey is performed.

- 1. WiFi Doctor Site Survey Panel
 - Listing all Site survey projects (Go to menu > WiFi Doctor)



• Click delete button to delete the corresponding project



• Click buttons below to view the details of corresponding project



2. Site Survey Details



Page Descriptions/Components (Go to menu > WiFi Doctor > click into details)

- Scan Result (Heatmap Type : Signal Strength) access point list scanned during passive survey
- Scan Result (Heatmap Type : Throughput) access point associated during active survey
- o Heatmap Type the map type will be generated and displayed
- Scale(Pixels per meter) the map scale used for Heatmap generation (*Please enter correct Map scale as it will affect the accuracy of the result*)
- Max Extropolate Distance(m) the maximum distance in meter away from survey points where the engine will "guess" a value according to the heatmap type
- Levels (Heatmap Type : Signal Strength) color range for signal strength in dBm
- Levels (Heatmap Type : Throughput) color range for throughput in Mbps
- o Number of APs number of access points scanned in the survey
- Number of Points number of survey points collected in the survey

2.1. Edit Survey Points

- Click 'Edit ' button
- Click on the survey point and then 'Delete Survey Point' button if you want to remove this point



- Drag and drop the survey point to adjust its location
- Click 'Save' to confirm changes
- Click 'Cancel' to undo changes

2.2. Signal Strength Heatmap Generation

- Choose Signal Strength as heatmap type
- Choose access points in the scan result
- Adjust parameters if needed
- Click 'Generate Heatmap'



2.3. Throughput Heatmap Generation

- Choose Throughput as heatmap type
- Choose access points in the scan result
- Adjust parameters if needed
- Click 'Generate Heatmap'



- 2.4. Export Result to PDF
- Adjust parameters for both Signal Strength and Throughput Heatamp
- Click 'Export'